Onan

Wiring Diagrams

for Mobile, RV and AUX GenSets

To be used ONLY by

Distributor Service Organization

or

Distributor/Dealer

WIRING DIAGRAMS FOR MOBILE ELECTRIC GENERATING SETS

All the wiring diagrams in this manual apply to Onan electric generator sets used in RV, AUX, or other special Mobile applications. When using the diagrams, remember that all components are shown in their de-energized position unless otherwise noted, Find the model in question in the left hand column (which matches the generator set nameplate), then look to the right for the applicable wiring diagram number and the page where it is located. For detailed service information, refer to the Master Service Manual for the respective unit, the RV Training Manual (932-0402) and the Controls Training Manual (932-0406).


MODEL NUMBER AND SPEC LETTER 2.5AJ-1E/6000K 2.5AJ-1E/12006K,M	WIRING DIAGRAM _ 605-0110 605-0110	SEE PAGE 8 8
2.7AJ-1R/12020K,M,N	611-1106	52
2.7AJ-1R/16010N	611-1106	52
2.7AJ-1R/16016N	611-1106	52
3.0AJ-1R/16017P,R	611-1140	61
3.0AJ-1R/16017S	611-1148	66
3.0AJ-1R/16018D,R,S	611-1148	66
2.5LK-1E/6000K,12006K,13036K,13036M	605-0110	8
2.5LK-1E/6820K,10819K	605-0083	5
2.5LK-1E/10898K	605-0107	6
205LK-1RV6000/1E,1F,1G,7060F,7193F,7740G	610-0266	12
205LK-1RV6000/1H	610-0313	14
205LK-1RV6000/7641G	610-0310	13
205LK-1RV6000/7641H	610-0320	17
2.5LK-1,2,3R/1C 2.5LK-1R/6000H,6000J,8098G,8486J,8781H,8782H,9525J, 9903H,9903J,10298H,10497H,10545L, 10545J,10689J,10801J,10850J,11215J, 11426J,12000J,12006J,12820J,13646J, 14185J,14185L	610-0266 610-0315	12 16
2.5LK-1R/10935J	605-0108	7
2.5LK-3CR/10801J	610-0338	18
2.5LK-3CR/10850J	610-0314	15
2.5LK-3CR/12000M,1L	610-0350	19
4.0BF-1R/9000A,14122A	611-1094	51
4.0BF-1R/9000B,9000C	611-1109	53
4.0BF-1R/9500A	611-1094	51
4.0BF-1R/15203B,15203C	611-1121	54
4.0BF-3CR/16000A,16002A	611-1123	55
4.0BF-3CR/16000B,16002B,16004B	611-1127	56
4.0BF-8R/16000B,17389B,20793B	611-1127	56
4.0BFA-1R/16000A,16004A	611-1135	59
4.0BFA-1R/16004B,16004C,16004D,16012C,17389C	611-1146	64
4.0BFA-1R/16015B,16015C,16020B,16020C	611-1147	65
4.0BFA-1R/16019A,16020A	611-1138	60
4.0BFA-3CR/15000C,20275A,20275C,22353C,22593C, 25206C,25505C,26651C,27014C, 27318C,27919C,26805C	611-1142	63
4.0BFA-5DR/22540C,22541C	606-0205	9


MODEL NUMBER AND SPEC LETTER	WIRING DIAGRAM	SEE PAGE
RV Gasoline (Continued) 4.0BGE-1R/26100A,26100B,26100C,26101A,26101B,26101C, 26102A,26109A,26109B,26109C,28202C	611-1174	. 76
4.0BGEL-1R/26110A,26110B,26111A,26111B,26112A	611-1174	76
5.0BGA-3CR/16000A 5.0BGA-3CR/16019A,16020A 5.0BGA-3CR/16004B,16004C 5.0BGA-3CR/16015B,16015C,16020B,16020C	611-1135 611-1138 611-1146 611-1147	59 60 64 65
4.0BGD-FB/1932A,7512A,30503A,30504A	611-1182	79
4.0BGE-1R/26100D,26100E,26101D,26101E,26109E 4.0BGE-1R/26100F,26101F,26109F	611-1174 611-1180	76 78
4.7BGE-1R/26100A,26101A	611-1174	76
4.0BGE-3CR/28202C,28202E,30981E	611-1176	. 77
4.0BGEL-1R/26110D,26111B,26111D	611-1174	76
5.0BGM-FA/26105A	611-1186	81
4.0CCK-**R/1J 4.0CCK-1R/1J through 23J,1681J,6000J,7723J,8010J,8782J 4.0CCK-1R/6000N,6000P,8643P,9290N,9525N,9525P,9625N	611-0236 611-0914 611-1035	23 30 36
10108N,10108P,10298P,11411P,11497P 4.0CCK-1R/8216J,8444J,9633P,9638N 4.0CCK-1R/8793J,9470P,9620N,9840N,10476N,10476P, 11191P,11586P,11673P,11852P	611-1 00 2 611-1036	35 37
4.0CCK-1R/8815J 4.0CCK-1R/9403J,10156J,10729J 4.0CCK-1R/9381N	611-1039 611-1049 611-1054	39 41 44
4.0CCK-3R/6000J 4.0CCK-3R/6000P,9381N,9381P	611-0839 611-1067	27 46
4.0CCK-3CR/6000J 4.0CCK-3CR/6000P,9525P 4.0CCK-3CR/6000R,9525R,11693R,11721R,12000R,12019R, 12273R,12276R,13290R,14608R,16557R	611-0975 611-1035 611-1086	34 36 50
4.0CCK-3CR/17389U 4.0CCK-3CR/15000U,16000U,16004U,20887U,21378U, 22650U,23659U,24044U	611-1127 611-1142	56 63
5.0CCK-1R/1A 5.0CCK-2R/1A 5.0CCK-1RV6000/1J,5360J,6000J,7036J,7036P,1681J,12J 5.0CCK-1RV6000/13J 5.0CCK-1R/8216J,8444J,9469J,9633N 5.0CCK-1R/6000N,6000P,8643P,8686P,8779J,9290N,9525N, 9525P,9625N,9641N,9701N,10108P,	611-0176 611-0176 611-0914 611-0957 611-1002 611-1035	22 22 30 32 35 36
10476N,10476P,10883P,11040P,11479P 5.0CCK-1R/8815J 5.0CCK-1R/9403J 5.0CCK-1R/9470N,9470P,9620N,11191P,11852P,12015P	611-1039 611-1049 611-1036	39 41 37
5.0CCK-3RV/4262J,4262F,5662J 5.0CCK-3RV/5121J 5.0CCK-3RV/5222J 5.0CCK-3RV/5605J 5.0CCK-3RV/5262J 5.0CCK-3CRV6000/1J,5360J 5.0CCK-3CRV6000/12J 5.0CCK-3RV6000/13J 5.0CCK-3RV6206J,7823J	611-0676 611-0786 611-0801 611-0164 611-0871 611-0839 611-0975 611-0963 611-0902	24 25 26 21 28 27 34 33 29


MODEL NUMBER AND SPEC LETTER RV Gasoline (Continued)	WIRING DIAGRAM	SEE PAGE
5.0CCK-3CR/6000R,10108R,11979R,12000R,12019R,12233R, 12276R,13040R,14618R,14780R,16437R,	611-1086	50
16557R,16778R 5.0CCK-3CR/9329J,9494N 5.0CCK-3CR/9403J 5.0CCK-3CR/9433J,9433N 5.0CCK-3CR/8793J,9525N,9620N 5.0CCK-3CR/1U,2U,3U,15000U,20508U,21378U,23034U	611-1047 611-1061 611-1050 611-1036 611-1142	40 45 42 37 63
5.0CCK-4R/18089U,16000U,17386U,17789U	611-1127	56
5.0CCK-4R/23969U	611-1142	63
5.0CCK-5DR/12018R,12233R	611-1086	50
5.0CCK-5DR/17233U	611-1127	56
6.0CCKB-3R/6000B,7821B,8327B 6.0CCKB-3R/6000C,6000D,7821C,7821D,8327C,8779B,9525C 9525D,9525E,10339C,11544D,12000D, 12000E	611-0955 611-1037	31 38
7.5DKD-FJ/27798C,27799C	AC 612-6184	82
7.5DKD-FJ/27798C,27799C	DC 612-6353	83
8.0DKD-3CR/29686B	AC 612-6442	85
8.0DKD-3CR/29686B	DC 612-6441	84
8.0DKD-FJ/29686C,32448C	AC 612-6442	85
8.0DKD-FJ/29686C,32448C	DC 612-6441	84
15.0DL3-J/30437A;30438A	AC 612-6460	86
15.0DL3-J/30437A,30438A	DC 612-6442	85
2.2KV-FA/26100A	610-0375	20
2.8KV-FA/26100A	610-0375	20
6.0NH-1R/9000A,9500A	611-1094	51
6.0NH-1R/9000E,9000G,9000H	611-1109	53
6.5NH-3CE/10000D,21880L	606-0215	: 11
6.5NH-3CE/16375D,16777D	606-0209	10
6.5NH-3CR/6000A,10005A 6.5NH-3CR/6000B,6000C,8686C,10005C,10182C,10621C, 11590C,11632C,11845C	611-1052 611-1079	43 48
6.5NH-3CR/10250A 6.5NH-3CR/10760C 6.5NH-3CR/1D,9D,12D,13D,14D,6000D,12000D,12230D, 12894D,15336D	611-1076 611-1080 611-1086	47 49 50
6.5NH-3CR/15000D,15000L,18768L,19701L,23033L, 23034L,25051P	611-1142	63
6.5NH-3CR/16000J,16002J,16004J,17789J,18629J	611-1127	56
6.5NH-3CR/16000A,16000K,16004K	611-1135	36
6.5NH-3CR/16004M,16004N,16004P,16013P,26785P	611-1146	64
6.5NH-3CR/16019K,16020K,20909K	611-1138	60
6.5NH-3CR/16020M,16020N,16020P	611-1147	65
6.5NH-3CR/17198D,18105D,18106D	611-1134	58
6.3NHEL-1R/26110D,26111D	611-1174	76
6.5NHEL-1R/26110C,26111C	611-1174	76
6.5NHE-1R/26100C	611-1174	76
6.5NHE-1R/26100D,26100E,26101D	611-1180	78
6.5NHE-FA/26101E	611-1180	78
6.5NHE-3CR/30982C,30983C	611-1176	77


MODEL NUMBER AND SPEC LETTER	WIRING DIAGRAM	SEE PAGE
RV Gasoline (Continued)		
6.3NHL-3CR/16013P 6.3NHL-3CR/16014P	611-1167 611-1169	73 74
6.3NHEL-1R/26110A,26111A	611-1174	76
6.5NHE-1R/26100A.26101A	611-1174	76
AUX Sets	•	
4.0BFA-1R/23000C,23001C,23003C,23004C 6.5NH-3CR/23000P,23001P,23002P,23003P,23004P 3.0RDJA-1R/23001U	611-1160 611-1160 611-1163	69 69 70
4.0DKC-3CR/23006B ¹ ,23007B ² 7.5DKD-3R/23008B,23009B 7.5DKD-3R/23008B,23009B 7.5DKD-3CR/23006B ¹ ,23007B ² 7.5DKD-5DR/23006B 7.5DKD-5DR/23006C,23007C,23008C,23009C 7.5DKD-FB/23006C,23007C,23008C,23009C	AC 612-6184 AC 612-6184 DC 612-6353 DC 612-6353 AC 612-6184 DC 612-6353 AC 612-6184 DC 612-6353	82 82 83 83 82 83 82 83
Diesel RV Sets		,
7.5DKD-3CR/27798A ¹ ,27798B ² 7.5DKD-3CR/27799A ¹ ,27799B ² 7.5DKD-FJ/27798C,27799C 7.5DKD-FJ/27798C,27799C 8.0DKD-3CR/29686B 8.0DKD-3CR/29686B 8.0DKD-FJ/29686C,32448C 8.0DKD-FJ/29686C,32448C 15.0DL3-J/30437A,30438A 15.0DL3-J/30437A,30438A 12.0RDJC-3R/21680AC	AC 612-6184 DC 612-6353 AC 612-6184 DC 612-6353 AC 612-6442 DC 612-6441 AC 612-6442 DC 612-6441 AC 612-6442 DC 612-6460 612-5787	82 83 82 83 85 84 85 84 86 71
Mobile and Commercial Units 4.0BFA-5DR/29309D (Time Manufacturing) 4.5BGD-FB/1A,30502A 4.5BGD-FD/1A,30502A 6.5NH-5DR/26725P (Gen Cable) 6.3NHD-FB/1932A,1932B,7512A,7512B,30503A,30503B, 30504A,30504B	611-1142 611-1182 611-1184 611-1170 611-1182	63 79 80 75 79
6.5NHD-FB/1A,1B,30502A,30502B 6.5NHD-FD/1A,1B,30502A,30502B	611-1182 611-1184	79 80
REPLACEMENT CONTROLS FOR 300-0859 PRINTED CIRCUIT BOARD KIT NUMBER 300-1598 CCK,NH with Onan Choke (RV)	611-1141	62
300-1599 CCK,NH with Sisson Choke (RV) 300-2026 CCK,NH with Onan Chike & Start-Disconnect for RV 300-2027 CCK,NH with Sisson Choke & Start-Disconnect for RV 300-1884 Standard CCK,NH with Onan Choke 300-1885 Standard CCK,NH with Thermo-Magnetic Choke	611-1141 611-1157 611-1157 611-1152 611-1152	62 68 68 67 67


¹⁼STD FAN ROTATION 2=REV FAN ROTATION

































"Merchan


To the second































25/



















































































































































































Onan

Onan Corporation 1400 73rd Avenue N.E. Minneapolis, MN 55432 1-800-888-ONAN 612-574-5000 International Use

Telex: 275477 Fax: 612-574-8087

Onan is a registered trademark of Onan Corporation